

Operating Instructions Und Bedienungsanleitungen Notice d'utilisation



PV Electronic Spa/Turbo Control

Doc N. [G-ARED]

Rev. Draft 0

Author: RT

Date 24-Aug-2013





INTRODUCTION

The Pegasus Electronic-PLUS HYDRO includes a water level sensor. When sufficient water is in the bath, the red LED on the touch pad will illuminate. The green LED on the pad indicates there is power to the unit.

OPERATION

Fill the bath with water to above the waterlevel sensor. Press the I/O button once, and the blower will activate at full power. Press the "Speed" button once will cause the blower will drop to it's minimum speed setting.

POWER: Pressing the speed button again will make the Blower go up one step in power, keep repeating the presses up to the fifth press, where the Blower will be at full power again.

WAVE: With the Blower turned on, press and hold the speed button for approximately 4 seconds to activate the built in "wave" function, which causes the Blower to automatically increase and decrease in power, this is at a set rate.

AUTOPURGE: Upon emptying the bath, the red LED will go off on the pad as the water level drops under the level sensor. After approximately 10 minutes, the blower will automatically activate and enter the blow dry cycle in order to blow out any remaining water from the system pipework. The blow dry cycle is only for a brief time.

TECHNICAL: 230/240 Vac - 50/60Hz – IPx5 – 5w

HOLE SIZES: Control: 29mm

TECHNICAL SUPPORT

Our technical support Hotline can be contacted on 01633 244555 (Ext 3) during normal working hours, Out of hours Tel: 07785 774411 or by email: technical@weuk.co.uk